





HOW TO PLACE AN ORDER

Sourced From MT Solar			
Product	Quantity	Description	
Ecobeam Core	1		The core includes hoistable frame, hardware to attach beams, and adjustable tilt bracket.
J-Hook (4 pcs)	1 per column of modules		The j-hooks attach rails to I-beams.
Angle Clamp Kit (4 pcs)	1 per column of modules		Alternate rail attachment for use in 5 row configurations. The Angle Clamps are 4' long and provide two rail attachment points to reduce rail cantilever and increase rail capacity.
15' Beam Kit	1 kit per EcoBeam Core		An option to provide beams versus sourcing locally. These ready-made beams mount to the EcoBeam core and span 15 feet when spliced together.
Hoisting Kit	1 per pole (re-useable)		Includes lifting bracket and pole insert to facilitate chain hoisting, also includes a safety chain. Can be re-used after installation on subsequent poles.
Chain Hoist	1 per pole (re-useable)		The chain hoist attaches to the lifting bracket and hoists the ecobeam core to final height after the modules are set. 2000 lb. load capacity, 15 ft. range